


# JZ

## Features

The JZ series pillar-type rubber vibration isolator is used for radio equipment to protect components and equipment from the effects of impact and vibration.



## Technical Data

Type	Model No.	Rated Load ( kg )	Z-Axis Deformation ( mm )	Damping Ratio ( C/Cc )	Temperature ( °C )
JZ	4	0.72-1.54	0.05	-40~+50	0.012
	8	0.42 ~ 0.91			0.038
	15	0.6-1.4			0.064

## Installation Dimensions ( mm )

Type	Model No.	M	D	H	h
JZ	4	M5	20	30	9
	8	M8	30	30	9
	15	M10	40	40	10

